

Speedpro Imaging[®]

BANNER STAND INSTRUCTIONS

SETUP

- Swivel out the support feet under the base (if applicable)
- Insert the support pole into the base (1)
- Standing behind the pole, slowly pull the banner up by the top-rail straight as possible, with the pole between you and the banner.
- Avoid rubbing the graphic side against anything as you raise it
- Lean the graphic back and pull the banner out to its full height (2)
- Clip the top-rail to the top of the support pole
- Adjust leveling screws under the base (if applicable) (3)

TAKE-DOWN

- Tilt the banner stand back and remove the top-rail from the top of the support pole
- Slowly allow the graphic to retract back into the base
- Keep the banner as straight as possible so it does not rub on the sides
- Remove the pole from the base

STORAGE

- Always store your banner rolled up in the base of the stand
- Keep the base and hardware in the carrying case to avoid exposure to dust and moisture
- Do not expose to direct sunlight or extreme heat for long periods of time

CLEANING

- Clean dust from the banner with a Swiffer or similar product.
- Smooth Poly Banners may be lightly cleaned with soapy water and a rag
- Always allow banner to dry before retracting it back into the stand base
- A brush or other abrasive tools should not be used to clean the banner.
- Do not use any harsh cleaners or solvents to clean the banner or any part of the Banner stand

USE

- The Banner stand is for indoor use and fair weather, short term outdoor use.
- Avoid moving a stand that is setup: re-roll the banner into the base and then move it

